

6' Backless Bench

ASSEMBLY INSTRUCTIONS

Parts Included:

- 3 – Backless Bench Legs
- 1 – 6' Assembled Bench Lengths


Hardware Included:

- 12 – 4" Coated Steel Screws
- 1 – Square Drill Bit

Tools Needed:

- Power Drill with Square Bit
- or Screwdriver with Square Tip

 **Build the bench on a flat or level surface.**



Step 1 - Lay the Assembled Bench Length upside down on a clean level surface. Place the three backless bench legs in between the 2" x 2" runners. See photo above.

Step 2 - Screw 4 – 4" coated steel screws into each leg using the pre-drilled holes through the 2" x 2" runners. See the photo above. Repeat for all three legs.

Step 3 – Flip Bench upright. Your bench is complete. Enjoy!