

# 8' A-Frame Table

## ASSEMBLY INSTRUCTIONS

### Parts Included:



Table Top (1)



Table Seats (2)



A-Frame Legs (3)

### Hardware Included:

44 – 4" Lag Bolt  
8 – 6" Lag Bolt  
56 – 5/16" Washers

### Tools Needed:


1/4" or 9/32" Drill Bit (6" or longer)  
Power Drill or Screw Gun

**! Build the table on a flat or level surface.**

Step 1 – Place the table top on a flat, clean surface with the attached 2" x 4" facing up. You may want to place cardboard underneath to help keep clean and prevent scratching the top. Place the legs up against the outer 2" x 4" of the table top and fasten (6) 4" lag bolts vertically and (2) 4" lag bolts horizontally as shown in the photo below.



Step 4 – Flip the table over. Take the two seat lengths and line up with the 2" x 6" piece of the A-Frame legs. Fasten horizontally with (2) 4" lag bolts through each end of the leg piece into the 2" x 6" piece attached to the bottom of the seat. Next fasten (2) 6" lag bolts vertically through each leg flange into the seat length. Shown in photo below.



Your A-Frame Table is complete!

Step 2 – Then place the center leg. Place the leg against the side with the sticker. **Make sure the center leg is on the correct side or the leg will not line up with the seat holes.** Legs attached shown in Photo Below.



A slight upward bow in the table top at first is good as it will settle. If you get any scuffs or scratches on the table or seats, you can use a hand propane torch to touch them up by move very lightly over the area. Do NOT leave the flame in one area for an extended period or it will burn.